

iRecharge[™]
for iPod[®] shuffle

Instruction Manual





iRecharge for iPod® shuffle (Rechargeable Portable Power Pack)

Congratulations! Thank you for buying iRecharge for iPod shuffle by the makers of Cellboost. Before using your iRecharge please read this instruction manual to learn about its features and capabilities and how to get the best from it.

iPod shuffle is a registered trademark of Apple Computer, Inc.
Cellboost is a registered trademark of Compact Power Systems, LLC.
iRecharge is a trademark of Compact Power Systems, LLC.(CPS)




Contents

Product Overview	5
Getting Started	6
LED Charge indicator	7
Using your iRecharge	8
Charging Instructions	9
iRecharge Rapid Replacement 3-Year Warranty	10

iRecharge for iPod shuffle

Product Overview

1. iPod shuffle USB connection (to connect your iPod shuffle to the iRecharge)
2. USB connector port (to charge your iRecharge using the USB charging cable)
3. Charge indicator (LED)
4. Cap






Getting Started

Before using your iRecharge for the first time, you will need to fully charge its battery using the USB charging cable.

1. Connect the USB charging cable to the USB connector port on iRecharge and connect the other end to your PC's USB port.
2. Leave your iRecharge connected until it is completely charged (usually 2-3 hours). While iRecharge is charging, the LED indicator will be on. When charging is complete the LED will turn off.
3. When your iRecharge is fully charged, disconnect it and follow the "Using your iRecharge" instructions.






iRecharge for iPod shuffle

Charge indicators (LED)

The front panel of your iRecharge includes 1 LED to indicate the charge status or working status of the iRecharge battery.



LED Charge Indicator

When charging iRecharge.

LED ON : Charging

LED OFF : iRecharge is charged

When iRecharge is plugged to iPod

LED ON : Charging iPod shuffle


LED OFF : Your iPod shuffle is charged



iRecharge for iPod shuffle

Using your iRecharge

Now that your iRecharge is fully charged, connect your iPod shuffle to the iRecharge. To do this, just slide your iPod into the iRecharge from the top. The LED will be on when iRecharge is charging your iPod shuffle, and the LED will be off when the iPod shuffle is fully charged.






iRecharge for iPod shuffle

Charging instructions

You can charge iRecharge following the “Getting Started” instructions or charge the iRecharge and your iPod Shuffle at the same time.

1. Connect your iPod to the iRecharge. Slide your iPod in from top to bottom.
2. Connect the USB Charging cable to the USB port of your iRecharge and connect the other end to the USB port of your PC.
3. iRecharge is fully charged when the LED light turns off





iRecharge Rapid Replacement 3-Year Warranty Service

CPS' warranty obligations for iRecharge are limited to the terms set forth below: CPS warrants the iRecharge product against defects in materials and workmanship for a period of three (3) years from the date of original purchase ("Warranty Period").

If a defect arises and a valid claim is received by CPS within the Warranty Period, at its option, CPS will (1) repair the product at no charge, using new or refurbished replacement parts, (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product, or (3) refund the purchase price of the product.

EXCLUSIONS AND LIMITATIONS

CPS is not liable for any damage or your portable device or loss of any programs, data, or other information stored on any media contained within your device or any non-CPS product or part not covered by this warranty. Recovery or reinstallation of programs, data or other information is not covered under this Limited Warranty.

This warranty does not apply: (a) to damage caused by accident, abuse, misuse, misapplication, or non-CPS products; (b) to damage caused by service performed by anyone other than CPS; (c) to a product or a part that has been modified without the written permission of CPS; or (d) if any CPS serial number has been removed or defaced. TO THE MAXIMUM EXTENT PERMITTED BY LAW, THIS WARRANTY AND THE REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. CPS SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IF CPS CANNOT LAWFULLY DISCLAIM OR EXCLUDE IMPLIED WARRANTIES



UNDER APPLICABLE LAW, THEN TO THE EXTENT POSSIBLE ANY CLAIMS UNDER SUCH IMPLIED WARRANTIES SHALL EXPIRE ON EXPIRATION OF THE WARRANTY PERIOD. No CPS reseller, or agent is authorized to make any modification, extension, or addition to this warranty.

TO THE MAXIMUM EXTENT PERMITTED BY LAW, CPS IS NOT RESPONSIBLE FOR DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY, INCLUDING BUT NOT LIMITED TO, LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPROGRAMMING OR REPRODUCING, ANY PROGRAM OR DATA STORED IN OR USED WITH CPS PRODUCTS.

How to get Rapid Replacement warranty service:

1. For information on obtaining Rapid Replacement warranty service, email CPS customer service at **customerservice@cpsystem.com**.
2. To obtain Rapid Replacement warranty service, you will be required to provide:
 - A. The original dated sales slip
 - B. Your name, address and email information
 - C. The serial number of the product
 - D. The product name, where purchased and a description of the problem.
3. Take or ship the product in the original or a properly padded, protective replacement box to CPS at the below address:

CPS Rapid Replacement Warranty Service
7801 Hayvenhurst Ave.
Van Nuys, CA 91406

iRecharge™

Cellboost™

Compact Power Systems, LLC.

www.Cellboost.com
(800) 833-1070